Quick start guide



ON/OFF: Hold 3 seconds to turn ON/OFF OXi-3



Switch modes:
Press to switch 12 licking modes.
Press to switch 3 suction modes.
Press to switch 12 vibrator modes.

How to Use



USB MAGNETIC CHARGING

- WARNING: PLease DO NOT use adaptor with “>5V" output
- Please make sure your toy is fully charged while the first time

1. Connect the device to USB port to charge.
2. Do not use the device while charging.Please connect with power adapter below 5V.
3. Can not keep in water for a long time.
4. If the product can't be charged when electrified,please wait for 10minsto confirm.





PRODUCT CLEANING

1. Clean Please clean product with warm water or antibacterial soap.
2. Wipe Dry the product with clean cloth or towel.
3. Store Keep the product in a cool, dry, clean place.
4. Attention Never clean this praduct with orgnic cleaner containingalcohol,gasoline or acetone.
5. Avoid direct sunlight.

SAFETY

1. Do not use it at temperature over 167°F/75°C.
2. Stop using it when any discomfort occurs.
3. It is recommended to use it with water-based lubricant.
4. Do not use it if you find the product unsmooth or damaged.
5. Keep out of reach of children.

Made in China